

# Packing up the Topaz CCTV

---

1. Push the x-y table as far back as it will go and lock into place.



Figure 1: Lock the x-y table.

2. Unplug the unit and fold up the cables.



Figure 2: Cables at the back of the CCTV.

3. Place the manual on the x-y table and place the Topaz in the plastic wrapping. Place the Topaz on the box base. The foam attached to the box base is shaped to fit around the left and right side of the CCTV base.



Figure 3: Box base with foam and CCTV.



4. Place the foam packaging on the left side of the monitor.



5. Place the foam packaging on the right side of the monitor.



6. Place the box cover over the monitor making certain the holes in the box cover match up with the holes in the box tray.



7. Insert the 4 plastic clips through the holes in the box and the box tray. Close the clips.

